PREVUE PET

Rabbit Playpen

Covers Models: # 460 (Small) / # 461 (Large)

CARE ADVISORY

To maintain the longevity of your purchase, we recommend that you

periodically treat it with a non-toxic sealant and protect it with a

read first **REVIEW BEFORE**

ASSEMBLY

BEFORE PROCEEDING, make sure you have purchased the correct Playpen for your Hutch.

- Assembly steps and hardware are the same for both playpen models. Parts differ in dimensions only.
- Tools are required for assembly. See below.
- For best results, follow steps in order.

TOOLS REQUIRED

Phillips-head screwdriver for all screws; if a power drill is used, do not overtighten-Prevue is not responsible for this type of damage. • Please follow the CARE ADVISORY to maintain product longevity.

For assistance or replacement parts, please contact Prevue Pet Products:

312.243.3624 PHONE

ONLINE www.prevuepet.com customerservice @ prevuepet.com EMAIL

ALL HARDWARE IS INCLUDED В A Ş

KEY TO HARDWARE SYMBOLS $A = 2^{3}/4^{"}$ wood screw $B = \frac{5}{8}$ wood screw

14 ct 24 ct





Α 800000 ×L

On the inside lip of the panels is a wood rail. Set the roof in place onto these rails.

Attach the panels together with [A] wood screws, using the predrilled starter holes as guides.



Fully open all panels.

Wood pegs, preset in the front and back panels, will align with predrilled guide holes on the side panels. Align the wood pegs with the guide holes, press

the panels together, make sure the seams are snug and tight.

Attach the panels together with [A] wood screws, using the predrilled starter holes as guides.





[6 sets of 4]

Note: All brackets will be mounted with [B] wood screws. There are no predrilled starter holes.

ROOF LATCHES (x2): Lay the C-Hook hardware in place before attaching. The bracket with the C-Hook should be on the outer edge, facing in [see Fig. 2.1]. Mount the C-Hook bracket first. Place the receiving bracket next to its partner, test the C-Hook alignment, then mount the 2nd bracket.

HUTCH LATCHES (x4): Place Hutch and Playpen on a level surface. Mount the bracket with the C-Hook on the Playpen edge [see Fig. 2.2]. Place the receiving bracket next to its partner, test the C-Hook alignment, then mount the 2nd bracket.

Two latches on each side. Test each one after mounting.





В

Ş