


# Follow this pecking order

Instructions online at [www.prevuepet.com](http://www.prevuepet.com)

# 1




## READ THESE INSTRUCTIONS!

Follow the enclosed Assembly Steps for a successful outcome. If you still have questions, we're here to help. Please contact our Prevue Customer Service team via email at :

[customerservice@prevuepet.com](mailto:customerservice@prevuepet.com)



# 2




## HELPFUL TOOLS

To assemble the coop, you will require a **phillips-head screw driver** or power tool with phillips head bit, and a **rubber mallet**.

NEEDED



# 3




## FIND A FRIEND

A second person's assistance is a necessity during several stages of assembly and for moving the assembled coop to your desired location.

# 4

EASY AS 1-2-3 !



## REVIEW ALL PARTS & HARDWARE

After unpacking all components, review all parts against the Parts List. Count the contents of the screw and dowel packets and compare the counts against the Parts List. There should be one spare for each packet.

If any packets are short, please contact Prevue or use your own appropriate-size replacements. Please contact Prevue if any problems or issues arise.


# 5

**CARE ADVISORY** To maintain the longevity of your purchase, we recommend that you periodically treat it with a non-toxic sealant and protect it with a tarp or other covering during extended periods of inclement weather.

# 6

## FIND A LEVEL SURFACE

Build your coop on a flat surface and, with a friend, carry it to the location where it will be used. Assembling the coop on the flattest surface available will help you greatly when squaring up panels and aligning the roof panels.



# 7



## SPECIAL ATTENTION NOTICE

### ASSEMBLY STEP 5: Frame alignment is critical for successful assembly


1. Square up the coop framework first, before applying the roof panels. This is the single most-important step you can take to guarantee the best roof alignment. An aligned frame will result in a more solid, stable assembly and nicer finished product.

2. Position the roof panels in place over the **chicken run area**. Check alignment. Position the roof panels over the

coop house area. Check alignment.

3. When all panels have been placed in position and aligned, *then* attach each with the appropriate screws.

**REMEMBER:** *DO NOT* screw the roof panels down until the coop frame has been squared up and all roof panels have been laid in position and evenly aligned.



**CUSTOMER SUPPORT**

For assistance or replacement parts,  
please contact Prevue Pet Products:

**PHONE** 1 (312) 243-3624

**ONLINE** [www.prevuepet.com](http://www.prevuepet.com)

**EMAIL** [customerservice@prevuepet.com](mailto:customerservice@prevuepet.com)

**KEY:**

CB = Coop Back

CC = Coop Center

CE = Center Extenders


CF = Coop Front

NB = Nest Box

RP = Roof Panel

RE = Roof End

RT = Roof Trim




**CUSTOMER SUPPORT**

For assistance or replacement parts,  
please contact Prevue Pet Products:

**PHONE** 1 (312) 243-3624

**ONLINE** [www.prevuepet.com](http://www.prevuepet.com)

**EMAIL** [customerservice@prevuepet.com](mailto:customerservice@prevuepet.com)



\*

These parts are  
interchangeable  
for themselves:

All **RP 1s**

All **RP 2s**

All **RP 3s**

All **RE 1s**

All **RE 2s**


All **RE 3s**

All **RT 1s**


All **RT 2s**

**HARDWARE:**


(spares are included but not reflected in counts)




**P**  
**Wood Peg**  
**28 pcs**




**P1**  
**2 3/8" L (60.5 mm)**  
**4 pcs**




**P2**  
**2" L (51 mm)**  
**8 pcs**



**P3**  
**1 3/4" L (44.5 mm)**  
**22 pcs**



**P4**  
**1 3/8" L (35 mm)**  
**56 pcs**



**P5**  
**1" L (25.5 mm)**  
**40 pcs**





**P6**  
**5/8" L (16 mm)**  
**6 pcs**

**TOOLS REQUIRED:**

**Screwdriver or power drill  
with Phillips head bit**

**Rubber mallet**





# 4-6 hen Chicken Coop ASSEMBLY

Instructions online at [www.prevuepet.com](http://www.prevuepet.com)

## CUSTOMER SUPPORT

For assistance or replacement parts, please contact Prevue Pet Products:

**PHONE** 1 (312) 243-3624

**ONLINE** [www.prevuepet.com](http://www.prevuepet.com)




**EMAIL** [customerservice@prevuepet.com](mailto:customerservice@prevuepet.com)

TOOLS: Phillips head screwdriver / Rubber mallet • For best results, follow the Assembly Steps in the order presented.


## KEY:

CB = Coop Back NB = Nest Box  
CC = Coop Center RP = Roof Panel  
CE = Center Extenders RE = Roof End  
CF = Coop Front RT = Roof Trim

## 1 PIECES




**PREP:** Tap wood pegs into predrilled holes indicated by the ▼ symbol.






*If a dowel snaps in the hole:  
a.) Drill the hole out and replace with a spare  
b.) Use a spare screw  
c.) Use a nail*



*Dowels are mainly for guidance when aligning panels and are not structural.*



Align wood pegs with the predrilled guide holes and attach the panels together with **[P3]** screws.




# 2 PIECES




## COOP FLOOR:

Set the coop floor panels into the coop base.




## PERCH BARS:


Insert the roosting perch bars into the notched holders.




## ROOF EXTENDERS:



**PREP:** Tap wood pegs into predrilled holes indicated by the ♣ symbol on all roof extender pieces.





view from FRONT




view from BACK



**PREP:** Arrange the pieces. Viewed from the front, roof extenders with the most extreme end-angle cuts are positioned on the outside.




Align the wood peg on the back of the extender with the guide hole on the coop door frame. Attach middle extenders first. Attach all with **[P2]** screws.



# 3 PIECES




## ENDS:





2 per side

Attach nest box ends with [P3] screws.



## FLOOR PREP:


**PREP:** Center the divider stop bar from side-to-side and flush with the outer edge.



Attach with [P3] screws.

## FLOOR:


Tip the nest box floor into position between the end panels with the divider stop bar facing the coop interior.



## SIDE:




Attach the nest box side with [P5] screws.




## DIVIDERS:

Insert the nest box dividers into the slots by tipping the inside corner (1) in first and rotating the outside corner (2) down into place.




## LID:

**PREP:** Before attaching the nest box lid, lay it in position and close the padlock flap over the corresponding hardware. This will align the nest box lid in the correct position.




NB 5


Attach the nest box lid hinges to the coop with [P6] screws.




# 4 PIECES



× 4




× 4




× 6



CF 1





CF 2




CF 3





**PREP:** Tap wood pegs into predrilled holes indicated by the ▴ symbol.




**ATTENTION:** When attaching the chicken run side panels and the front panel, make sure the panels align flush with the outside edges.




Align the side panels flush with the coop and attach with **[P1]** screws.




Align the front panel flush with the sides and attach with **[P3]** screws.








To assure a clean finish to your coop, pay special attention to the **coop frame alignment**. Squaring up your frame will result in the correct alignment for the roof panels, roof seams, and all roof trim.



### GOOD ALIGNMENT IS EVERYTHING

◀ A diagram of the coop framework as viewed from above, showing square 90° corners and perfect, flush alignment of all coop frame panels.

An off-kilter frame alignment will make it difficult to place the roof panels correctly; will create poor roof seams; will make it difficult to finish the end trim neatly or align the top trim correctly, and; will result in a jagged and sloppy coop roof.



### ROOF PANEL PLACEMENT GUIDE



PLACEMENT  
GUIDE ONLY.  
See next page  
for Assembly  
Steps.

**PREP:** Lay all roof panels face-down on the ground, following the order and placement shown ➡

*NOTE: Numbered roof parts follow this pattern:*

- All ①s are center panels.
- All ②s & ③s are outer-edge panels, and have asphalt coating wrapping around to the outside edges.



numbering stamps  
are for identification

guide holes closest to the edge  
are for the middle seam



asphalt-coating wraps  
around to the sides  
on outer-edge panels

Roof panels, asphalt-side down ➡

Roof panels, on the coop ↓



# 5 PIECES




## BEGIN WITH THE CHICKEN RUN END:

Lay panels ② & ③ in position. Align the wood pegs along the roof lines with the guide holes on the panel undersides. If dowels and guide holes don't properly align, gently adjust the coop frame until alignment is achieved.

Lay center panels ① & ① in position.

**DO NOT ATTACH PANELS.** Check the roof panel alignment. Adjust the coop frame as necessary to get as straight an alignment as possible.

*A jagged, uneven, stair-stepped alignment along the roof panels means the coop frame is not aligned. Shift the coop frame right or left to get a clean alignment edge.*





## COOP HOUSE END:

Place panels over the Coop House end, using the same method: outer-edge panels first, then center panels.

Recheck the alignment and adjust as necessary.



With roof panels aligned, starting with the center panels/middle seam, begin attaching the roof to the frame.



## ROOF END CAP TRIM:



Attach the two middle ① end trim first.

Align the outer-edge ② & ③ trim off of the middle pieces.



**PREP:** Lay the roof seam trim in position FIRST and adjust for the cleanest alignment.

- ① trim slats are positioned along the peak.
- ② trim slats are positioned over the side seams.



Assembly completed. ■

