

**HARDWARE
INCLUDED:**



Hex Screw
26 pcs +1



Corner Bracket
4 pcs



Endcap
4 pcs



Allen wrench
1 pcs



Plastic Connector
4 pcs



Rolling Caster
2 pcs



Locking Caster
2 pcs

KEY:

B = BACK Panel

R = RIGHT Side Panel

C = CORE Center Parts


F = FRONT Panel

L = LEFT Side Panel



G = GRILLE

T = TRAY

D = DIVIDER





1 PIECES



INSTALLATION TIP :


Use the allen wrench to keep the plastic connector from going too deeply into the frame, and to align the holes in the post and frame.

Insert the **plastic connectors** into the top of the stand frames.
Align the bottom hole of the connector with the hole on the frame leg.




1
Hand-tighten the hex screws at the top to attach stand frame sides to the front and back frames.

Leave screws LOOSE for the next step.




2
Insert the extended wires of the **storage shelf** into the holes along the inside lower rails of the front and back frames.

Finish the stand assembly with hand-tightened hex screws at the bottom corners, and then tighten **ALL** screws with the hex key.



3
Insert **casters** into the base of the frame legs. Position the **two locking casters** where you find them best suited for your expected use.

2 PIECES




L 2 and **R 2**
are interchangeable

NOTE : For Steps 2 and 3, the **cage body** will be assembled **UPSIDE DOWN** for ease of assembly.


Turn the **front panel** and **right side panel** upside-down.

Guide the extended wires on the side panel into the holes along the inside frame of the front panel.


Secure the panels together with hex screws.



Add the **back panel** and **left side panel** in the same method, securing all panels together with hex screws.





3 PIECES



C 2 and **C 3**
are interchangeable

C 4 **C 5** and **C 6**
are interchangeable




With the cage body still upside down, install the two **tray channel rails**. Orient the channels as shown in the detail.

Attach the channels with hand-tightened hex screws.


After the tray channel rails are attached, install a **square rail** with hex screws.

Tighten all screws with the hex key.




3 continued...

Flip the cage body upright




Turn the cage body upright.


Slip the assembled cage unit over the corner connectors on the cage stand.






Install the two remaining **square rails**. Secure the rails with hex screws.



4 PIECES



grilles and trays are interchangeable




Insert the slotted ends of the **perches** on a vertical wire and resting on a horizontal wire or frame rail.

Slide the cup doors up and insert the **food/water cups**. The closed door holds the cup in place.




Rotate the **grille/tray lock** out of the way and slide the **grill** into the top channels and the **tray** into the bottom channels for each cage side.

4 continued...




Leave the center **divider grille** out for full-cage use, or slip it in place to divide the cage interior into two separate spaces.


5 PIECES



Set the **roof panel** into place. Back the corner screw out and slip a **corner bracket** over the corner as shown in the detail. Tighten the screw to secure the bracket on the corner. Repeat the method for all corners to fully secure the roof in place.

Tap the **endcaps** into each corner to finish off the assembly.



Assembly completed. 

Hampton Deluxe Cages

HOW TO STACK ASSEMBLED UNITS

Instructions online at www.prevuepet.com

CUSTOMER SUPPORT

For assistance or replacement parts,
please contact Prevue Pet Products:


PHONE 1 (312) 243-3624

ONLINE www.prevuepet.com

EMAIL customerservice@prevuepet.com

1

PIECES



INSTALLATION TIP :

Use the allen wrench to keep the plastic connector from going too deeply into the frame, and to align the holes in the post and frame.

TOOLS NEEDED :

An allen wrench and maybe a screwdriver or pliers to help in removing endcaps.

1. REMOVE ENDCAPS

From the top unit, remove the footer endcaps.

From the bottom unit, remove the top endcaps.

2. REMOVE HEX SCREWS

From the bottom unit, remove the four top corner hex screws.

3. INSERT PLASTIC CONNECTOR POSTS

Into the frame corners of the bottom unit, insert the plastic connectors, following the INSTALLATION TIP at the top of the page.

4. REPLACE HEX SCREWS

On the bottom unit, replace the hex screws in each corner, making sure to keep the corner brackets in place.

5. STACK THE UNITS

After all corner connectors and corner brackets are installed securely, slide the frame corners of the top unit over the connector posts on the bottom unit.

- Three cage units can be stacked safely.
- Do not exceed three stacked cages.

